



最佳控制压力

Optimum control pressure



- Ⓐ 工作压力 (输送压力)
- Ⓑ + 压差
(Δp 控制压力与工作压力之间)
- Ⓒ = 要设置的最佳控制压力
(闭合压力)

- Ⓐ Operating pressure (line pressure)
- Ⓑ + Differential pressure
(Δp between control pressure and working pressure)
- Ⓒ = Optimum control pressure to be set
(closing pressure)

压缩空气 (最佳控制压力) 需要多少巴, 以便能关闭夹管阀?

How much compressed air (control pressure) is required to close the pinch valve?

最佳控制压力 =

工作压力	+	压差
- 客户要求		- 见铭牌 见技术信息表“内衬套质量”

OPTIMUM CONTROL PRESSURE =

Operating pressure	+	Differential pressure
- Customer specification		- see type plate (techn. info sheet sleeve qualities)

提示:
夹管阀的最大控制 / 工作压力在铭牌或数据表中!

Note:
Please refer to the type plate or article text for the maximum control / operating pressure of the pinch valve!